


TİP / TYPE / TYP

İRA - İRAM }  
 İRF - İRFM } 181  
 İRBM }



**Yedek Parça Listesi****General Parts List****Einzelteilliste**

TİP / TYPE / TYP

İRA / İRF / İRAM / İRFM / İRBM } 181

1- Gövde	1- Gear Case	1- Getriebegehäuse
2- Milli Dişli Z3	2- Gear Z3	2- Ritzelwelle Z3
3- Kama	3- Key	3- Passfeder
4- Dişli Z2	4- Gear Z2	4- Rad Z2
5- Rulman	5- Bearing	5- Lager
6- Segman	6- Circlip	6- Sicherungsring
7- Milli Dişli Z5	7- Gear Z5	7- Ritzelwelle Z5
8- Rulman	8- Bearing	8- Lager
9- Kama	9- Key	9- Passfeder
10- Dişli Z4	10- Gear Z4	10- Rad Z4
11- Segman	11- Circlip	11- Sicherungsring
12- Rulman	12- Bearing	12- Lager
13- Segman	13- Circlip	13- Sicherungsring
14- Segman	14- Circlip	14- Sicherungsring
15- Çıkış Mili	15- Output Shaft	15- Abtriebswelle
16- Kama	16- Key	16- Passfeder
17- Dişli Z6	17- Gear Z6	17- Rad Z6
18- Rulman	18- Bearing	18- Lager
19- Rulman	19- Bearing	19- Lager
20- Ön Kapak	20- Front Cover	20- Abtriebsdeckel
21- Keçe Kapağı	21- Seal Cover	21- Dichtringflansch
22- Keçe	22- Seal	22- Wellendichtring
23- Cıvata	23- Bolt	23- Sechskantschraube
24- Cıvata	24- Bolt	24- Sechskantschraube
25- Flanş	25- Flange	25- Flansch
26- Cıvata	26- Bolt	26- Sechskantschraube
27- Kama	27- Key	27- Passfeder
28- Motor	28- Electric Motor	28- Elektromotor
29- Motor Bağlantı Kapağı	29- Motor Mounting Adapter	29- Motoranschlussflansch
30- Cıvata	30- Bolt	30- Sechskantschraube
31- Kama	31- Key	31- Passfeder
32- Kama	32- Key	32- Passfeder
33- Dişli Z1	33- Gear Z1	33- Ritzel
34- Segman	34- Circlip	34- Sicherungsring
35- Segman	35- Circlip	35- Sicherungsring
36- Rulman	36- Rulman	36- Lager
37- Motorsuz Giriş Mili	37- Input Shaft	37- Antriebswelle
38- Motorsuz Kapak	38- Gear Case Cover	38- Antriebsdeckel
39- Keçe Kapağı	39- Seal Cover	39- Dichtringflansch
40- Keçe	40- Seal	40- Wellendichtring
41- Cıvata	41- Bolt	41- Sechskantschraube
42- Cıvata	42- Bolt	42- Sechskantschraube
43- Kama	43- Key	43- Passfeder
44- Taşıma Kancası	44- Lifting Eye Bolt	44- Ringschraube
45- Havalandırma Cıvatası	45- Vent Plug	45- Entlüftungsschraube
46- Yağ Seviye Tespit Cıvatası	45- Oil Level Plug	46- Ölstandschraube
47- Yağ Boşaltma Cıvatası	47- Drain Plug	47- Verschluss-Schraube