



TİP / TYPE / TYP

İRSD - İRSDM } 161  
İRSDF - İRSDFM }



**Yedek Parça Listesi****General Parts List****Einzelteilliste****TİP / TYPE / TYP****İRSĐ / İRSĐF / İRSĐM / İRSĐFM } 161**

1- Gövde	1- Gear Case	1- Getriebegehäuse
2- Segman	2- Circlip	2- Sicherungsring
3- Rulman	3- Bearing	3- Lager
4- Sonsuz Vida	4- Worm	4- Schnecken
5- Kama	5- Key	5- Passfeder
6- Dişli Z2	6- Gear Z2	6- Rad Z2
7- Segman	7- Circlip	7- Sicherungsring
8- Tapa	8- Locking Cap	8- Verschlusskappe
9- Kovan	9- Hollow Shaft	9- Hohlwelle
10- Kama	10- Key	10- Passfeder
11- Sonsuz Vida Çarkı	11- Worm Wheel	11- Schneckenrad
12- Rulman	12- Bearing	12- Lager
13- Segman	13- Circlip	13- Sicherungsring
14- Keçe	14- Seal	14- Wellendichtring
15- Burç	15- Spacer	15- Stützscheibe
16- Motor	16- Electric Motor	16- Elektromotor
17- Kama	17- Key	17- Passfeder
18- Dişli Z1	18- Gear Z1	18- Ritzel Z1
19- Segman	19- Circlip	19- Sicherungsring
20- Cıvata	20- Bolt	20- Sechskantschraube
21- Motorsuz Kapak	21- Gear Case Cover	21- Antriebsdeckel
22- Segman	22- Circlip	22- Sicherungsring
23- Rulman	23- Bearing	23- Lager
24- Giriş Mili	24- Input Shaft	24- Antriebswelle
25- Kama	25- Key	25- Passfeder
26- Cıvata	26- Bolt	26- Sechskantschraube
27- Keçe	27- Seal	27- Wellendichtring
28- Kama	28- Key	28- Passfeder
29- Üst Kapak	29- Upper Cover	29- Getriebedeckel
30- Cıvata	30- Bolt	30- Sechskantschraube
31- Taşıma Kancası	31- Lifting Eye Bolt	31- Ringschraube
32- Havalandırma Cıvatası	32- Vent Plug	32- Entlüftungsschraube
33- Yağ Seviye Tespit Cıvatası	33- Oil Level Plug	33- Ölstandschraube
34- Yağ Boşaltma Cıvatası	34- Drain Plug	34- Verschluss-Schraube
35- Flanşlı Kapak	35- Flange	35- Flansch
36- Cıvata	36- Bolt	36- Sechskantschraube