






 <p>P₁</p>	 <p>P₅</p>	
 <p>P₃</p>	 <p>P₆</p>	
 <p>Yağ doldurma - Havalandırma Vent plug Valve d'aération</p>	 <p>Yağ seviye tespit Oil level Niveau d'huile</p>	 <p>Yağ boşaltma Drain plug Bouchon de drainage</p>



TİP Type Type	Bağlantı pozisyonları için yağ miktarları (litre) Oil quantities for mounting positions (liter) Quantités d'huiles en fonction de la position de montage (Litre)			
	P ₁	P ₃	P ₅	P ₆
İRCM 73	3,4	2,7	2,7	2,6
İRCM 83	4,6	4,2	4,4	4,2
İRCM 93	9,6	7,8	9,1	8,3
İRCM 103	18	15,3	18	18,5
İRCM 123	34	21	24	24