

Semboller :
Seymbols :
Seymboles :



Yağ Doldurma ve Havalandırma
Oil Filling and Vent Plug
Valve d'aération




Yağ Seviye Tespit
Oil Level
Niveau d'huile



Yağ Boşaltma
Oil Drain Plug
Bouchon de drainage

TİP Type	Bağlantı Pozisyonları ve Yağ Miktarları (litre) Oil Quantities for Mounting Positions (liter) Quantités d'huiles en fonction da la position de montage (litres)											
	P1	V1	P2	V2	P3	V3	P4	V4	P5	V5	P6	V6
	MK.... 504-503 / G07-G09	23		35		20		31		37		36
MK.... 604-603 / G07-G09	26		39		22		34		41		40	
MK.... 704-703 / G07-G09	38		55		32		49		59		56	
MK.... 804-803 / G07-G09	42		65		36		54		67		64	
MK.... 904-903 / G07-G09	52		81		45		76		84		80	
MK.... 1004-1003 / G07-G09	59		92		51		82		94		90	



Semboller :

Symbols :

Symboles :



Yağ Doldurma ve Havalandırma

Oil Filling and Vent Plug

Valve d'aération



Yağ Seviye Tespit

Oil Level

Niveau d'huile



Yağ Boşaltma

Oil Drain Plug

Bouchon de drainage

TİP Type	Bağlantı Pozisyonları ve Yağ Miktarları (litre)											
	Oil Quantities for Mounting Positions (liter)											
	Quantités d'huiles en fonction de la position de montage (litres)											
	P1	V1	P2	V2	P3	V3	P4	V4	P5	V5	P6	V6
MK.... 503 / G08-G10	23		35		21		31		37		36	
MK.... 603 / G08-G10	25		39		23		34		41		40	
MK.... 703 / G08-G10	38		55		33		49		59		56	
MK.... 803 / G08-G10	42		65		37		54		67		64	
MK.... 903 / G08-G10	50		81		47		76		84		80	
MK.... 1003 / G08-G10	58		92		53		82		94		90	