


Yedek Parça Listesi


General Parts List

Einzelteilliste

TİP / TYPE / TYP

İRSA - İRSAP - İRSAM } 52-65-82-102-127-162
İRSF - İRSFP - İRSFM }



**Yedek Parça Listesi****General Parts List****Einzelteilliste****TİP / TYPE / TYP****İRSA / İRSF / İRSAP / İRSFP / İRSAM / İRSFM } 52-65-82-102-127-162**

1- Gövde	1- Gear Case	<i>1- Getriebegehäuse</i>
2- Rulman	2- Bearing	<i>2- Lager</i>
3- Sonsuz Vida (Giriş Mili)	3- Worm (Input Shaft)	<i>3- Schnecke (Antriebswelle)</i>
4- Rulman	4- Bearing	<i>4- Lager</i>
5- Segman	5- Circlip	<i>5- Sicherungsring</i>
6- Segman	6- Circlip	<i>6- Sicherungsring</i>
7- Tapa	7- Locking Cap	<i>7- Verschlusskappe</i>
8- Keçe	8- Seal	<i>8- Wellendichtring</i>
9- Kama	9- Key	<i>9- Passfeder</i>
10- Sonsuz Vida Çarkı	10- Worm Wheel	<i>10- Schneckenrad</i>
11- Rulman	11- Bearing	<i>11- Lager</i>
12- Büyük Kapak	12- Big Cover	<i>12- Abtriebsdeckel</i>
13- Keçe	13- Seal	<i>13- Wellendichtring</i>
14- Cıvata	14- Bolt	<i>14- Sechskantschraube</i>
15- Flanş	15- Flange	<i>15- Flansch</i>
16- Cıvata	16- Bolt	<i>16- Sechskantschraube</i>
17- Motor	17- Electric Motor	<i>17- Elektromotor</i>
18- Kama	18- Key	<i>18- Passfeder</i>
19- Motor Bağlantı Flanşı (IEC)	19- Motor Mounting Adapter (IEC)	<i>19- Motoranschlussflansch (IEC)</i>
20- Cıvata	20- Bolt	<i>20- Sechskantschraube</i>
21- Sonsuz Vida (Motorlu)	21- Worm (For Electric Motor)	<i>21- Schnecke (Für Elektromotor)</i>
22- Cıvata	22- Bolt	<i>22- Sechskantschraube</i>
23- Havalandırma Cıvatası	23- Vent Plug	<i>23- Entlüftungsschraube</i>
24- Yağ Seviye Tespit Cıvatası	24- Oil Level Plug	<i>24- Ölstandschraube</i>
25- Yağ Boşaltma Cıvatası	25- Drain Plug	<i>25- Verschluss-Schraube</i>